



Starting / Full load current (DOL)	6.4
Starting / Full load current (Y/D)	
Rotor Inertia	
Bearing DE	620
Bearing NDE	620

We make all efforts to better our products. Versions, technical data and figures could be changed therefore. They are not binding before written confirmation.