



Starting / Full load current (DOL)	5
Starting / Full load current (Y/D)	
Rotor Inertia	
Bearing DE	6
Bearing NDE	6

We make all efforts to better our products. Versions, technical data and figures could be changed therefore. They are not binding before written confirmation.