


## How do I wire a Force Ventilation Unit

FUV-G type force ventilation units have wiring detail in the terminal box lid and are suitable for 230V 3 phase, 400V 3 phase and 240V single phase. Please see below example of wiring details:


### Star Configuration

If the supply is 415V three phase



### Delta Configuration

If the supply is 220V three phase



### Steinmetz Configuration

If the supply is 230V single phase

